A/C Unit Instructions

NOTE: Please read all instructions before operation of the air-conditioning unit.

1. Before operation, remove cap on top of unit.



2. Check water level gauge and fill unit with WATER only. **DO NOT** fill unit past red marker on gauge.



3) Check water levels frequently after every use to ensure optimal performance of a/c unit.